


Instructions


Analog output module

AK-OB 110




CE

Montage / Assembly / Einbau / Montaje



Tilslutning / Connection / Anschluß / Raccordement / Conexión



	Modul Module Módulo	Punkt Point Punto	Type Typ Tipo	Max
AO1	1	24	0 - 10 V	2.5 mA
AO2	1	25	0 - 10 V	2.5 mA

